

Salada	495'
Base Salt	1255'
Gates	1830
Rivers	

352' TOC →

8 5/8" CSNG
@ 510' w/d
SCSKS. Cmt
10 7/8 hole

SAH
sho' plug 395 to 560
Per & squeeze
TAG

← plug 1600' → TAG

1736' ← TOC

5 1/2' cshg
@ 1916' wt
50 sxs. cmt
8 1/4 hole

Aug 1916' TAG

TD 2044'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

MLB