

January 16, 1962

Mr. Dick Morris
Oil Conservation Commission
Post Office Box 871
Santa Fe, New Mexico

Dear Dick:

Plugging program for Western Drilling Company Inc., all wells
to be loaded with heavy mud before plugging.

Platt # 1 SW SW 26-18S-26E

1. 1125' to 927' 30 sacks.
2. 790' to 635' 25 sacks.

Platt # 1-A SW SW 26-18S-26E

1. 6405' to 6208' 25 sacks.
2. 5560' to 5363' 15 sacks.
3. 1115' to 1040' 15 sacks.
4. 760' to 715' 15 sacks
(This well may be producing.)

Platt # 2 NE SW 26-18S-26E

1. 1211' to 938' 25 sacks.
2. 891' to 816' 25 sacks.
3. 760' to 715' 15 sacks.
(This well drilled to about 100' with no casing.
Fill hole with earth or mud to surface and set
marker.)

Platt # 3 NW SW 26-18S-26E

1. 1105' to 973' 25 sacks.
2. 891' to 846' 15 sacks.
3. 760' to 715' 15 sacks.
(This well may be producing.)

Remarks: Dry hole marker and surface plug must be set in addition to the above specified plugs.

Very truly yours,
Oil Conservation Commission

N. L. Armstrong
Supervisor, District #2

LA/jw

10/1/50

10/1/50
10/1/50
10/1/50
10/1/50

10/1/50

10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50

10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50
10/1/50