

30-015-06115

1220

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

RECEIVED

MAR 22 1968

OFFICE

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
----------------------------	---	------------------------------

5. State Oil & Gas Lease No.

647

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator American Petrofina Company of Texas	8. Farm or Lease Name Resler Yates State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 307
4. Location of Well UNIT LETTER <u>AH</u> 1843 FEET FROM THE <u>North</u> LINE AND 1165 FEET FROM THE <u>East</u> LINE, SECTION <u>28</u> TOWNSHIP <u>18S</u> RANGE <u>28E</u> NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3547 GR.	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Ran 2" EUE tubing to 2150' and spotted 50 sack cement plug on bottom using 10# mud.
2. Pulled tubing.
3. Shot off 5 1/2" casing at 1164'.
4. Spotted 25 sack cement plug at 1104'.
5. Spotted 25 sack cement plug at 500'.
6. Pulled 5 1/2" casing out of hole.
7. Loaded hole with 10# mud.
8. Set 5 sack cement at surface and placed 4 1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman Cliff Chapman TITLE Petroleum Engineer DATE March 21, 1968

APPROVED BY J. P. J. Larson TITLE Assistant Engineer DATE March 21, 1968

CONDITIONS OF APPROVAL, IF ANY: