

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

REVISED

| |
|---|
| WELL API NO. 30-015-10090 |
| 5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/> |
| 6. State Oil & Gas Lease No. B-5084-76 |
| 7. Lease Name or Unit Agreement Name WLHU G4S Unit Tract |
| 8. Well No. 25-2 |
| 9. Pool name or Wildcat Loco Hills Queen-GB-San Andres |
| 10. Elevation (Show whether DF, RKB, RT, GR, etc.) |

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
YATES PETROLEUM CORPORATION

3. Address of Operator
105 South 4th St., Artesia, NM 88210

4. Well Location
Unit Letter K : 1650 Feet From The South Line and 1980 Feet From The West Line

Section 1 Township 18S Range 29E NMPM Eddy County

| | |
|---|---|
| 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data | |
| NOTICE OF INTENTION TO: | SUBSEQUENT REPORT OF: |
| PERFORM REMEDIAL WORK <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> |
| OTHER: <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| | CASING TEST AND CEMENT JOB <input type="checkbox"/> |
| | OTHER: <input type="checkbox"/> |

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. NOTIFY OCD-ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING

Propose to plug and abandon as follows:

1. TOOH with 2-3/8" tubing
2. TIH with wireline and set CIBP at 2610'. TOOH. TIH with tubing and tag CIBP. Load hole with plugging mud. Spot a 25 sack Class C cement plug from 2610-2310'.
3. TOOH with tubing. TIH with casing guns and perforate 4-1/2" casing with 6 holes at 1200' and 6 holes at 467'.
4. TIH with wireline set cement retainer at 1100'. TOOH. TIH with tubing. Load hole with plugging mud. Sting into retainer and establish injection rate. Mix & pump 75 sacks Class C cement. Leave 35' of cement on top of retainer. TOOH with tubing.
5. TIH with wireline set cement retainer and set retainer at 367'. TOOH. TIH with tubing and load hole with plugging mud. Sting into retainer and establish circulation. Mix & pump 60 sacks Class C cement from 467-367' to squeeze. Leave 35' of cement on top of retainer. TOOH with tubing.
6. Spot a 15 sack Class cement plug at surface.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Operations Technician DATE Jan. 21, 2000

TYPE OR PRINT NAME Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY Mike Steinfeld TITLE Field Rep. II DATE 2/9/2000

CONDITIONS OF APPROVAL, IF ANY:

* Notify NMUCN to witness Plugging Operations.