

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE
3 (Other instructions on re-
lease slips)

Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-068402

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

North Benson Queen Unit

8. FARM OR LEASE NAME

9. WELL NO.

12

10. FIELD AND POOL, OR WILDCAT

North Benson Queen Graybu

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 29, T18S, R30E

12. COUNTY OR PARISH

Eddy

13. STATE

Lea

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection Well

2. NAME OF OPERATOR

Texaco Inc. ✓

3. ADDRESS OF OPERATOR

PO Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)

At surface

Unit Letter J, 1980' FSL & 1980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3453' DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

Temporary Abandon

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Reclassify from SI-INJ to TR-INJ (Held for Remedial Work)

- 1) MIRU pulling unit. Install BOP. Pull tubing and packer.
- 2) By wireline, RIH with gauge ring and junk basket to $\pm 2600'$. POH. RIH with CIBP and set at $\pm 2570'$ (top perf at 2613'). Dump 35' of cement on top of CIBP with dump bailer. POH.
- 3) RIH with tubing to $\pm 2500'$. Circulate hole with inhibited fluid.
→ Test csg. to 500 psi for 15 minutes. (675)
- 4) POH and lay down tubing. Rig down pulling unit.

18. I hereby certify that the foregoing is true and correct

397-3571

SIGNED

TITLE Hobbs Area Superintendent

DATE 5/18/88

(This space for Federal or State office use)

ORIG. SCD. PAJ GIRI

APPROVED BY BILL R. RESOURCES

TITLE

DATE

6-13-88

CONDITIONS OF APPROVAL, IF ANY:

Subject to
Like Approval
by State

*See Instructions on Reverse Side