

30-015-1042C

K-17-18-28

Aceco Prod.

Welch ST. #4.

12"- 328'

* Perforate 4 1/2" casing @ 50'.
circulate cement to surface
inside & outside 4 1/2" csg.

10" csg

504'.

* Perforate 6 5/8" casing @ 554'.
Squeeze 100' cement Plug inside & outside 6 5/8" csg. TAG.

* Circulate brine gel to surface.

6 5/8"-
1978'

* Run & set either 255x cement Plug @ 1878' TAG
or CIBP @ 1878' w/ 35' cement on top CIBP.

TD - 2474.