Operator Weil Unit API #	<u>Maljamar</u> <u>A'State #2</u> <u>A</u> Section <u>36</u> Twnship <u>17</u> Range <u>30-015-16474</u>	31
391- (ak Toc	€ - Euris & Plug	
858 1040	of Shos Plug 440-1373 Tag	

3594 - Cale

3914 -3458 ⁻ I <→ 3865 = Perfs Tag

Rustler Salado Base Salt /

TOPS

yates	2170
7 nivers	25841
Duren	31851
Grayburg	3660 '
San Andres	39631

800

* Contact OCD 24 hrs. prior to any work done.

- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' 60'
- * Where plugs are required, cernent must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

*

۰,

1