

YATES PETROLEUM CORPORATION  
WHLU G4S Tract 3-4  
Section 12-T18S-R29E  
Eddy County, NM

5. TIH with wireline set cement retainer & set retainer @351', TOH. TIH with tubing. Sting into retainer & establish circulation. Squeeze with 75 sacks Class C cement from 351-451'. Leave 35' of cement on retainer. TOH with tubing.

6. Spot 15 sack Class C cement plug at surface.

7. Install regulation abandonment marker.

Notify BLM – Carlsbad (505-234-5909) and OCD – Artesia (505-748-1283) 24 hours prior to commencing plugging operations.

---

Rusty Klein  
Operations Technician  
May 22, 2001