Operator United oil & Minerals, Inc.
Well N. Benson Queen UT. #3
Unit D Section 32 Twnship 18 Range 3c
API # 30-0 15- 10874

TOPS

Rustler	270'
Salado	410'
B Salt	1230'
Gates	1430'
Queen	2530'

250' - to surface

shoe & salt plug 360'-530' - Tag

1430' Tag

2700' Tag

Puts

1 5/8"
480'
400 SXS
circ

2708 -
3054

4 1/2 @ 3110'
800 SXS
6 3/4 hole
Calc circ

* Contact OCD 24 hrs. prior to any work done.
* Salt gel mud consisting of 10# brine with 25#
  of gel per barrel must be placed between each
  plug.
* Install dry hole marker as per Rule 202.B.2
* Plugs are to be set from point indicated **up**.
* Plugs must not be less than 100' or 25 Sacks
  of cement, whichever is greater, unless
  specifically indicated.
* Shoe and stub plugs will be 50' above and below
  shoe or stub and tagged.
* Surface plug will be from 0' - 60'
* Where plugs are required, cement must be
  placed inside and outside of **all** casing string(s)
  in the correct footage or sacks required, **if no
  cement exists.**
* Plugs to be tagged will be indicated.