## State of New Mexico

P.O. Box 2088   Santa Fe, New Mexico   Santa Fe, New	Submit 3 Copies to Appropriate District Office	P.O. Box 2088		Revised 1-1-89	
STATE   FEE	DISTRICT I P.O. Box 1980, Hobbs, NM 88240				
SUNDRY NOTICES AND REPORTS ON WELL C. C. C.  SUNDRY NOTICES AND REPORTS ON WELL C. C. C.  SUNDRY NOTICES AND REPORTS ON WELL C. C. C.  SUNDRY NOTICES AND REPORTS ON WELL C.	DISTRICT II P.O. Drawer DD, Artesia, NM 88210	Santa Fe, New Mex	ico <u><u>R</u>250417888</u>	5. Indicate Type of Lease STATE FEE X	
Type of Well:   ONTER   PEAN   Hornbaker BA	DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410		FEB 2 5 1992	6. State Oil & Gas Lease No.	
Ones P&A  Name of Operator  Not the the strip of the strip	DIFFERENT RESE	RVOIR. USE "APPLICATION FOR	R PERMIT"	7. Lease Name or Unit Agreement Name	
2. Name of Operator VATES PETROLEUM CORPORATION  3. Address of Operator 10.5 South 4th St., Artesia, NM 88210  4. Well Location Unit Letter G: 1900 Feet From The North Line and 1650 Feet From The East Line Section 2.5 Township 188 Range 2.5E NMFM Eddy County 10. Elevation (Show whether DF, RKB, RT, GR, etc.)  11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMPORABILY ABANDON CHANGE PLANS CASING TEST AND CEMENT JOB  DITHER:  12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  Plugged and abandoned well as follows: 2-18-92. RU. POH and laid down 93 - 5/8" rods. POH with tubing. Set CIBP at 2107'. Dumped 6 sx cement on CIBP. Set CIBP 1350', dumped 6 sx cement on CIBP at 1350'. POH with tubing to 1125'. Spot 25 sx cement plug. POH with tubing to 60'. Circulate 10 sacks cmeent to surface. POH with tubing. Dug out cellar. Cut off wellhead.  Installed dry hole marker.  WELL PLUGGED AND ABANDONED 2-20-92.  1 Inertoy certify that the information above is gibe and complete to the best of my knowledge and belief.  Therety certify that the information above is gibe and complete to the best of my knowledge and belief.  The Production Supervisor DATE 2-25-92		] OTHER ]	P&A	Hornbaker BA	
Note	2. Name of Operator	RATION V			
Unit Letter G: 1900 Feet From The North Line and 1650 Feet From The East Line Section 25 Township 18S Range 25E NMPM Eddy County 10. Elevations (Show whether DF, RKB, RT, GR, etc.)  11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO:  SUBSEQUENT REPORT OF:  REMPORABLY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDON CHANGE PLANS CASING TEST AND CEMENT JOB OTHER:  11. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  Plugged and abandoned well as follows:  2-18-92. RU. POH and laid down 93 - 5/8" rods. POH with tubing. Set CIBP at 2107'.  Dumped 6 sx cement on CIBP. Set CIBP 1350', dumped 6 sx cement on CIBP at 1350'.  POH with tubing to 1125'. Spot 25 sx cement plug. POH with tubing to 60'. Circulate 10 sacks cmeent to surface. POH with tubing. Dug out cellar. Cut off wellhead.  Installed dry hole marker.  WELL PLUGGED AND ABANDONED 2-20-92.	3. Address of Operator 105 South 4th St., Arr	tesia, NM 88210			
Section 10 Manager 10. Elevation (Show whether DP, RRB, RT, GR, etc.)  11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  NOTICE OF INTENTION TO:  SUBSEQUENT REPORT OF:  REMEDIAL WORK ALTERING CASING  CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT OTHER:  OTHER:  12. Describe Proposed or Completed Operations (Clearly state all pertinent datals, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  Plugged and abandoned well as follows:  2-18-92. RU. POH and laid down 93 - 5/8" rods. POH with tubing. Set CIBP at 2107'.  Dumped 6 sx cement on CIBP. Set CIBP 1350', dumped 6 sx cement on CIBP at 1350'.  POH with tubing to 1125'. Spot 25 sx cement plug. POH with tubing to 60'. Circulate 10 sacks cmeent to surface. POH with tubing. Dug out cellar. Cut off wellhead.  Installed dry hole marker.  WELL PLUGGED AND ABANDONED 2-20-92.  Thereby ceptify that the information above is give and complete to the best of my knowledge and belief.	4. Well Location  Unit Letter $G$ : 190	OO Feet From The North	Line and165	0 Feet From The East Line	
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  NOTICE OF INTENTION TO:  SUBSEQUENT REPORT OF:  REMEDIAL WORK PLUG AND ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING TEST AND CEMENT JOB OTHER:  12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  Plugged and abandoned well as follows:  2-18-92. RU. POH and laid down 93 - 5/8" rods. POH with tubing. Set CIBP at 2107'.  Dumped 6 sx cement on CIBP. Set CIBP 1350', dumped 6 sx cement on CIBP at 1350'.  POH with tubing to 1125'. Spot 25 sx cement plug. POH with tubing to 60'. Circulate 10 sacks cmeent to surface. POH with tubing. Dug out cellar. Cut off wellhead.  Installed dry hole marker.  WELL PLUGGED AND ABANDONED 2-20-92.  Py H  I hereby ceptify that the information above is give and complete to the best of my knowledge and belief.	Section 25	Township 18S	Range 25E sether DF, RKB, RT, GR, etc.)	NMPM Eddy County	
NOTICE OF INTENTION TO:  SUBSEQUENT REPORT OF:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  CHANGE PLANS  COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING TEST AND CEMENT JOB  OTHER:  12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.  Plugged and abandoned well as follows: 2-18-92. RU. POH and laid down 93 - 5/8" rods. POH with tubing. Set CIBP at 2107'.  Dumped 6 sx cement on CIBP. Set CIBP 1350', dumped 6 sx cement on CIBP at 1350'.  POH with tubing to 1125'. Spot 25 sx cement plug. POH with tubing to 60'. Circulate 10 sacks cmeent to surface. POH with tubing. Dug out cellar. Cut off wellhead.  Installed dry hole marker.  WELL PLUGGED AND ABANDONED 2-20-92.  Thereby cerify that the information above is give and complete to the best of my knowledge and belief.  Thus Production Supervisor Date 2-25-92					
Plugged and abandoned well as follows:  2-18-92. RU. POH and laid down 93 - 5/8" rods. POH with tubing. Set CIBP at 2107'.  Dumped 6 sx cement on CIBP. Set CIBP 1350', dumped 6 sx cement on CIBP at 1350'.  POH with tubing to 1125'. Spot 25 sx cement plug. POH with tubing to 60'. Circulate 10 sacks cmeent to surface. POH with tubing. Dug out cellar. Cut off wellhead.  Installed dry hole marker.  WELL PLUGGED AND ABANDONED 2-20-92.  PATO-2 3-13-92 PATO-1  Thereby cerify that the information above is the and complete to the best of my knowledge and belief.  THE Production Supervisor DATE 2-25-92	PERFORM REMEDIAL WORK  TEMPORARILY ABANDON  PULL OR ALTER CASING  DTHER:	PLUG AND ABANDON	CASING TEST AND C	IG OPNS. PLUG AND ABANDONMENT	
Production Supervisor DATE 2-25-92	Plugged and aband 2-18-92. RU. PO Dumped 6 sx cemen POH with tubing t 10 sacks cmeent t Installed dry hol	oned well as follows H and laid down 93 - t on CIBP. Set CIBP o 1125'. Spot 25 sx o surface. POH with e marker.	: 5/8" rods. POH v 1350', dumped 6 s cement plug. POH	with tubing. Set CIBP at 2107'.  Ex cement on CIBP at 1350'.  H with tubing to 60'. Circulate cellar. Cut off wellhead.	
SIGNATURE L'ante De ollie TILE Production Supervisor DATE 2-25-92	I hereby certify that the information above is	the and complete to the best of my knowle	dge and belief.		
	SIONATURE ( anda)	a ollis	mme Production	Supervisor DATE 2-25-92	

Juanita Goodlett TYPE OR PRINT NAME TITLE Field Rep. I DATE Sept. 17-1992 CONDITIONS OF AFPROVAL, IF ANY: