

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

APR 30 1975

O.C.C.

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. NM 443
7. Unit Agreement Name
8. Farm or Lease Name State "AL"
9. Well No. 1
10. Field and Pool, or Willcat Artesia
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator ARWOOD, LTD.
3. Address of Operator Petroleum Bldg-Tower Suite; Roswell, N.M. 88201
4. Location of Well UNIT LETTER K, 1650 FEET FROM THE South LINE AND 2310 FEET FROM THE West LINE, SECTION 20 TOWNSHIP 18S RANGE 28E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3579 G.L. 3590 K.B.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

11" hole. Ran 13 jts. 8 5/8" 24#, set @ 500' with 350 sxs. + 2% CaCl2
7 7/8" hole. Ran 62 jts. 5 1/2", 14#, set at 2492' with 300 sxs +6% gel and 5#/sx of salt followed by 150 sx. neat + 2% CaCl2. T.D. 2494.PBTD 2443'. BP @ 2048: Perfs 1987-97

- 1)* Set 100' cement plug from 2048-1948.
- 2) Shoot off 5 1/2" csg.
- 3) Spot 100' plug across stub of 5 1/2" csg. and mud between plugs.
- 4) Spot 100' plug across shoe of 8 5/8" and mud between plugs.
- 4a) If casing stub and shoe are approximately same depth, use one plug for 3&4 above.
- 5) Set 25' plug and surface marker with mud between plugs.
- 6) Clean up location.

Work to commence May 5th or 6th. Mud 25#/gel/bbls.

*Minimum of 20 sx or if flowing water a BP w/ 30' of cement will be required

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNER J. M. T. Bayl TITLE Agent DATE 4/29/75

APPROVED BY W. A. Gussert TITLE SUPERVISOR, DISTRICT II DATE MAY 1 1975

CONDITIONS OF APPROVAL, IF ANY:
* as noted above.

Notify N.M.O.C.C. in sufficient time to witness
Plugging