

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE  
(Other instruction  
reverse side)

Form approved.  
Budget Bureau No. 1004-0-33  
Expires August 31, 1985

CLSF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐  
2. NAME OF OPERATOR  
3. ADDRESS OF OPERATOR  
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

RECEIVED  
MAR 10 10 31 AM '89

5. LEASE DESIGNATION AND SERIAL  
LC 066445

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

9. WELL NO.

10. FIELD AND POOL OR WILDCAT

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

12. COUNTY OR PARISH 13. STATE

Mewbourne Oil Company ✓  
P.O. BOX 5270 Hobbs, New Mexico

CEIVED

MAR 14 '89

990 Feet from east line

14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GK, etc.)

3289 GL

Sec. 1, Township 18  
So. R-26-E

Eddie New Mexico

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON\*

SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL

CHANGE PLANS

(Other)

(Other)

(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.)

1-30-89

Plugged well as follows:

Set CIBP at 8975 with 35 SXS Cement BX Dump Bailer TIH with tubing  
8940 ft Circulate hole with mud Pull to 7070 spot 30 SXS inside 5-1/2"  
to 6805 Cut & Pull 159 Jts 5-1/2" casing from 6320 TIH with tubing  
sopt 45 SXS 6395 WOC tag TOC 5984. Pull tubing to 4000 ft. spot 65 SXS  
On 2-1-89.

2-2-89 tag 3800 ft. pull to 2020 spot 40 SXS WOC tag 1807 ft pull  
tubing to 300 ft. Circulate cement to surf with 100 SXS .

Cut off wellhead install dryhole marker completed 2-2-89.

Mud between all plugs.

Post ID-2  
3-17-89  
P+H

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

President

DATE

March 3, 1989

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

3-13-89

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side