

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ TA gas well ☐ other
2. NAME OF OPERATOR ARCO Oil & Gas Company /  
Division of Atlantic Richfield Co.
3. ADDRESS OF OPERATOR  
P. O. Box 1710, Hobbs, New Mexico 88240
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1100' FNL & 1200' FWL  
AT TOP PROD. INTERVAL: as above  
AT TOTAL DEPTH: as above
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

- |                      |                                     |
|----------------------|-------------------------------------|
| TEST WATER SHUT-OFF  | <input type="checkbox"/>            |
| FRACTURE TREAT       | <input type="checkbox"/>            |
| SHOOT OR ACIDIZE     | <input type="checkbox"/>            |
| REPAIR WELL          | <input type="checkbox"/>            |
| PULL OR ALTER CASING | <input type="checkbox"/>            |
| MULTIPLE COMPLETE    | <input type="checkbox"/>            |
| CHANGE ZONES         | <input type="checkbox"/>            |
| ABANDON*             | <input checked="" type="checkbox"/> |
| (other) _____        |                                     |

## SUBSEQUENT REPORT OF:

- |  |
|--|
|  |
|  |
|  |
|  |
|  |
|  |
|  |

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Propose to P & A in the following manner:

1. Rig up, install BOP, POH w/comp assy. RIH w/bit & scraper, tag retr @ 5983'.
- \* 2. Spot 35' cmt plug on top of retr. @ 5983' using C1 "C" cmt contg 2% CaCl<sub>2</sub>.
3. Spot 25 sx cmt plug @ surf. Cut off wellhead below GL. Install regulation dry hole marker @ surf. Clean & level location for abandonment.

Additional plugs needed:  
100' cement plug 3350'-3450'  
" " " 920'-1020'

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.

- 18. I hereby certify that the foregoing is true and correct**

SIGNED James L. Schmitt TITLE Dist. Drlg. Supt DATE 4-16-82

APPROVED (This space for Federal or State office use)  
(Orig. Sgd.) PETER W. CHESTER


APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_

APR 23 1982

FOR

JAMES A. GILLHAM  
DISTRICT SUPERVISOR

\*See Instructions on Reverse Side



ARCO Oil & Gas Company

Division of Atlantic Richfield Company

**Blow Out Preventer Program**

**Lease Name** Empire Abo Unit "M"

**Well No.** 131

**Location** 1100' FNL & 1200' FWL  
Sec. 11-18S-27E Eddy County, N. M.

BOP to be tested when installed on well and will be maintained in good working condition during drilling. All wellhead fittings to be of sufficient pressure to operate in a safe manner.

*JWS*  
*4/16/82*