

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
J.S.G.S.	
LAND OFFICE	
OPERATOR	1

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

5a. Indicate Type of Lease

State ☒ For ☐

5. State Oil & Gas Lease No.

L - 1607

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT DEPTH. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

RECEIVED

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator Anadarko Production Company	9. Farm or Lease Name New Mexico State "AA"
3. Address of Operator P. O. Box 67, Loco Hills, New Mexico 88255	9. Well No. 1
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 35 TOWNSHIP 18S RANGE 28E NMPM.	10. Field and Pool, or without Wildcat Penn
15. Elevation (Show whether DF, RT, GR, etc.) 3481.5 GL	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER Abandon Strawn: Complete Upper Penn ☒	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

1. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pulling unit over hole.
2. Load tubing with 3% KCL packer fluid to kill well.
3. Remove X-tree and install BOP.
4. Unset packer & circulate 3% KCL water.
5. TOH with packer.
6. Run Wireline set CIBP and set @ 9925' to abandon Strawn.
7. Run Wireline dump bailer and spot 35' cement from 9925' to 9890'.
8. Perforate Upper Penn 9244-9248', 9398 - 9402' & 9538 - 9542' @ 2 SPF.
Note: If NMOCC objects to the set of perfs @ 9244 - 9248' being commingled with the perfs from 9398 - 9542', then the set of perfs @ 9244 - 9248' will be omitted.
9. Set packer @ approximately 9200' (50' above top perfs).
10. Remove BOP and install X-tree.
11. Acidize with 2400 gals acid and 20 BS.
12. Swab test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mike Brownell TITLE Field Foreman DATE November 25, 1981

APPROVED BY W.A. Gressett TITLE SUPERVISOR, DISTRICT II DATE DEC - 1 1981

CONDITIONS OF APPROVAL, IF ANY: