

HALLWOOD PETROLEUM, INC.

State "B" 14 COM #1

Empire Field

Eddy Co., NM

Proposed Procedure

1. MIRU workover rig.
2. POOH w/ production tubing.
3. RU WL truck and set CIBP @ $\pm 9500'$. Dump bail 20' of cement on same.
4. RIH and perforate WOLFCAMP from 9000-9111. RD WLU.
5. PU 4-1/2" production packer and GIH w/ 2-3/8" tbg. Set packer at $\pm 9100'$.
6. RU DOWELL. Acidize WOLFCAMP perfs. W/ 3000 gallons of 15% HCL + inhibitors. Displace w/ N_2 .
7. Test and evaluate well.