

9/12/00 SITP 0, SICP 10 psi.  
TIH w/new overshot to catch 1 1/4" rope socket, caught fish, POOH w/all the tools, start swabbing, FL @ 6800 ft.

9/13/00 PO: Swabbing. SITP 0, SICP 10 psi.  
IFL @ 6900'. Ending FL 7300', rec 90 bbls, total fluid rec 2720±

9/14/00 PO: Swabbing. SITP 0, SICP 10 psi.  
IFL @ 6800'. FFL @ 7300', rec 110 bbls, total fluid rec 2830 bbls wtr. SIFN.

9/15/00 PO: Swabbing. SITP 0, SICP 15 psi.  
IFL @ 7100'. Swabbed 130 bbls wtr, tot rec 2960 bbls, have show of gas w/each swab run. SI & SDFN.

9/16/00 PO: Swabbing. IFL 7300'. SITP 0, SICP 15 psi.  
Swabbed 130 bbls fluid w/gas blow while pulling swab. SIFN.

9/17/00 PO: Swabbing. 60-hr SI, SITP 0, SICP 15 psi.  
Swabbed 130 bbls total fluid rec 3220 bbls wtr, SI & SD for weekend.

9/18/00 SD

9/19/00 PO: SI well. SITP 0, SICP 15 psi. FL 7000'.  
Swabbed 130 bbls w/slight gas show, total fluid rec 3350 bbls ± , SI well & release swab rig

\*\*\*\*\*