

Acidize Bone Springs via tubing with 5000 gals 7-1/2% NEFE. POH with tubing.

Frac via casing; flow and/or swab test; set pumping equipment. Place well on pump.