

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
30-015-23713

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.
LC-058127

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
Anadarko Petroleum Corp.

7. Lease Name or Unit Agreement Name
Ballard Grayburg San Andres Unit

8. Well No.
26-3

3. Address of Operator
Box 2497; Midland, Texas 79702

9. Pool name or Wildcat
Loco Hills (Queen Grayburg San Andres)

4. Well Location
Unit Letter M : 700 Feet From The South Line and 430 Feet From The West Line

Section 4 Township 18-S Range 29E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Notify OCD 24 hrs prior to MI and minimum of 4 hrs prior to setting plugs.
- 2) NU tbg BOP, RIH w/ 3-7/8" bit on 2-3/8" workstring to 2,500'. POOH w/ bit.
- 3) Set CIBP @ 2,500'.
- 4) Circulate hole w/ mud, pump 15 sx C cmt on top of CIBP.
- 5) Pump 15 sx C cmt 1,033 - 833' (T/Yates @ 983'). 2558 cement Plug.
- 6) Pump 30 sx C cmt 430' to surface.
- 7) Cut off wellhead & anchors. Install dry hole marker. Cover workpit, cellar, and anchors. Leave location clean and clear of trash.

* Anticipate NMPM to - Texas Logging Operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Consulting Engineer

DATE 6/9/99

TYPE OR PRINT NAME

James F. Newman, P.E.

TELEPHONE NO. 915-687-1994

(This space for State Use)

APPROVED BY

TITLE

Field Rep. II

DATE

6/24/99

CONDITIONS OF APPROVAL, IF ANY: