

Memo

From
Larry Brooks
Geologist

To: P/A

- 1.) SET CIBP W/35' CMTT. ON TOP & LOAD HOLE
W/MUD.
- 2.) TOC: 2100 CUT & PULL 5 1/2"
- 3.) Pump 100' plug from 2150-2050 & TAG.
- 4.) Pump 100' plug from 1858-1758 & TAG.
- 5.) Pump 100' plug from 235-335
- 6.) Pump 15 sxs. @ SUR.

13 3/8 @ 285' Circ }
8 5/8 @ 1808 Circ }
5 1/2 TOC @ 2100' }