

Operator Dionexco, Inc.
 Well Ama 310041
 Unit A Section 8 Township 18 Range 28
 API # 30-015-24785

TOPS

Yates	530'
Trivers	806'
Powers	1211'
Queen	1446'
Grayburn	2006'
San Antonio	2306'

← 60' Surface Plug

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

8 5/8" (2306')
CIRC

← 530' TAG

← 2070' TAG

2120'-
2301'

← Perfs

5 1/2" @ 2476
CIRC

MLB