

CLSF

Form 3160-5
(June 1990)

RECEIVED

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

RECEIVED

2. Name of Operator
Premier Production Company

MAR 11 1993

3. Address and Telephone No.
P.O. Box 1246, Artesia, NM 88210

(505) 749-2293

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Section 23: SE/4 SW/4
T-18S R-29E

990 FSL E 1450' FWL

W.T.N

5. Lease Designation and Serial No.

NMNM17223

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Alice Federal #2

9. API Well No.

30015249700051

10. Field and Pool, or Exploratory Area

Turkey Track (SR,Q,GB,SA)

11. County or Parish, State

Eddy County, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☒ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Plug & Abandon

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plugged & abandoned well as per requirements. Ran 2" tubing to 2453'; circulated hole with 10# gelled mud. Spotted 65sx cement plug from 2453' back to 1775' (calculated); trip out with tubing. W.O.C. 2 hours; trip in to tag first plug. Tagged plug at 1800'. Pulled tubing to 975'; filled hole with 10# gelled mud; spotted 25sx cement plug at 975'. Pulled tubing to 400'; spotted 25 sx cement plug. Pulled up and spotted 10 sx plug in and out of casing. Installed and cemented 4" identifying marker. Cleaned up and ripped location; leveled and cut drain slope. Ready for inspection.

Part ID-2
3-19-93
PYA

Approved as to plugging of the well bore.
Liability under bond is retained until
surface restoration is completed.

14. I hereby certify that the foregoing is true and correct

Signed Paul White

Title Consulting Engineer

Date 2/25/93

(This space for Federal or State office use)

Approved by (FOR USE OF) DAVID R. GLASS

Title PETROLEUM ENGINEER

Date 3-9-93

Conditions of approval, if any: