

DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

C/SF  
FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Anadarko Petroleum Corporation

3. Address and Telephone No.

PO Box 37, Loco Hills, NM 88255 505/677-2411

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650' FNL & 2110' FWL  
Sec. 11, T18S, R28E

5. Lease Designation and Serial No.

NM-54184

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA, Agreement Designation

N/A

8. Well Name and No.

Federal 11 #1

9. API Well No.

30-015-25086

10. Field and Pool, or Exploratory Area

Empire South, Morrow

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. RU plugging unit.
2. Run freepoint & determine 100% free (csg). Chem cut at this point (100%).
3. TOH w/csg.
4. TIH w/tbg to 50' below cut off point. Circ hole w/Brine gel. Spot 150 sx Class C, plug w/2% CaCl.
5. Pull up hole @ 1000'. SD. WOC 12 hrs. Notify BLM.
6. Tag up on cement. (Lowest tag 50' above cut off).
7. Pull up hole to 2825' & spot 120 sx Class C Plug.
8. Pull up hole to 500' & spot 120 sx Class C Plug.
9. Spot 75 sx Plug @ surface.
10. Cut off & cap well head.
11. RD PU.
12. Plug & Abandon
13. Restore surface to BLM specifications.

SEE PAGE 2.

14. I hereby certify that the foregoing is true and correct

Signed Edward H. Herbert

Title Field Foreman

Date 08-28-97

(This space for Federal or State office use)

(ORIG 302) JOE G. LARA

Approved by  
Conditions of approval, if any:

Title Petroleum Engineer

Date 8/28/97