

COMPANY Salkar Inc.		PROPERTY NAME El Cheapo	FOOTAGE 1650 FNL & 1650 FWL
DATE	LOCATION (ULSTR) F-35-18-27		
API NO. 30-015-25238		POOL A-On-Ch. SA	

1. Spot a 40 Sx plug at 1800'. WOC and tag.
2. Load hole with mud from tag to 680'.
3. Pull up hole to 680' & fill to surface with cement.
4. Set dry hole marker, clean & level location.

Contractor will be responsible for condition of road and pad. Contractor will also handle any salvage.

CASING RECORD:

8 5/8 @ 278' C
4 1/2 @ 2140' C
TD 2220'
Top Perf @ 1516'

8 5/8 - 278'

T.Q. 12W

4 1/2 @ 2140'
W. LOSS
TD 2220'

* Set tubing @ 680' - circ to surface.
* Circ. brine gel.
* 40 Sx cement plug 1800' TAG

T. Perf. 1516'

8 5/8 @ 278'

Top Perf 1516'

4 1/2 @ 2140'

53 Sx to sur

Mud

40 Sx