

1-505-

Fap To Greg 397-6252
Newbome Oil Co
Turkey Trach 15 L#1
15-18-28-E

133/8 c 390' c
958 c 2628 c
5 1/2 c 10,864 c
PBTID 7897
Pays c 6418-28
TOS c 473
BOS c 585
Wates 744
Bu c 1702
SA c 2494
BS c 3655
2nd BS

- ① Tag CIBP c 7897 + cap if not capped w/cmt.
- ② Cover DV Tool w/100' plug c 7776.
- ③ Set CIBP c 6318 + cap w/35' cmt
- ④ Load hole w/25 lb per bbl salt gel + brine.
- ⑤ 25 sp c 3655
- ⑥ 25 sp c 2678'
- ⑦ 25 sp c 1702'
- ⑧ 25 sp c 600'
- ⑨ 25 sp c 390'
- ⑩ 10 sp surface plug
- ⑪ Set dry hole marker, cut anchors
clean bottom.
- ⑫ Notify OCD 24 hrs before.