Form 3160-5 (June 1990)

any matter within its jurisdiction.

UNI O STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED

Budget Bureau No. 1004-0135 Expires March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS	Lease Designation and Serial No.
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.	NM-7716
Use "APPLICATION FOR PERMIT—" for such proposals	6. If Indian, Allottee or Tribe Name
SUBMIT IN TRIPLICATE	NA
1. Type of Well	7. If Unit or CA, Agreement Designation
Type of Well	West Red Lake 8910089700
2. Name of Operator	8. Well Name and No.
DEVON ENERGY CORPORATION (NEVADA)	West Red Lake #78
3. Address and Telephone No.	9. API Well No.
20 NORTH BROADWAY, SUITE 1500, OKLAHOMA CITY, OKLAHOMA 73102 (405) 235-3611	30-015-29011
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)	10. Field and Pool, or Exploratory Area
2530' FNL & 1500' FWL; Unit "F" of Section 8-18S-27E	Red Lake (Q-GB-SA) 11. County or Parish, State
	
	Eddy County, NM
CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, F	REPORT OR OTHER DATA
TYPE OF SUBMISSION TYPE OF ACT	
	Change of Plans
Notice of Intent Abandonment Recompletion	New Construction
	☐ Non-Routine Fracturing
Subsequent Report □ Plugging Back	Water Chut Off
Casing Repair	☐ Water Shut-Off ☐ Conversion to Injection
Casing Repair	Conversion to Injection Dispose Water
☐ Casing Repair ☐ Altering Casing ☐ Other Completion ☐ Altering Casing ☐ Other Logical Completion ☐ Altering Casing ☐ Other Logical Completion Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of second complete Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of second complete Comple	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as follows: 15. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as follows: 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886',
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of s subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as foll 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.46)	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886',
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ O	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes).
☐ Final Abandonment Notice ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of s subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as foll 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.44 Acidized San Andres perfs 1540-1949' w/2500 gals of 15% NeFe acid, ISIP 1283#. Frac'd perfs 1540-1949' w/15,000 gals PrePad + 2 drum Pro-Kem scale inhibitor + 52 7000# 100 mesh sand + 252,000# 16/30 brady sand and 24,000# CRC sand. ISIP 2800	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes).
☐ Final Abandonment Notice ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of s subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as foll 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.44 Acidized San Andres perfs 1540-1949' w/2500 gals of 15% NeFe acid, ISIP 1283#. Frac'd perfs 1540-1949' w/15,000 gals PrePad + 2 drum Pro-Kem scale inhibitor + 52 7000# 100 mesh sand + 252,000# 16/30 brady sand and 24,000# CRC sand. ISIP 2800	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) Starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041#
☐ Final Abandonment Notice ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of s subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as foll 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.44 Acidized San Andres perfs 1540-1949' w/2500 gals of 15% NeFe acid, ISIP 1283#. Frac'd perfs 1540-1949' w/15,000 gals PrePad + 2 drum Pro-Kem scale inhibitor + 52 7000# 100 mesh sand + 252,000# 16/30 brady sand and 24,000# CRC sand. ISIP 2800	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) Starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041#
☐ Final Abandonment Notice ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of s subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as foll 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.44 Acidized San Andres perfs 1540-1949' w/2500 gals of 15% NeFe acid, ISIP 1283#. Frac'd perfs 1540-1949' w/15,000 gals PrePad + 2 drum Pro-Kem scale inhibitor + 52 7000# 100 mesh sand + 252,000# 16/30 brady sand and 24,000# CRC sand. ISIP 2800	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) Starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041#
☐ Final Abandonment Notice ☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion ☐ Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of s subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* On 7/30/96, RU Wedge WL. Ran Bond log from 2103' - surf Perf'd w/1 SPF as foll 1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.44 Acidized San Andres perfs 1540-1949' w/2500 gals of 15% NeFe acid, ISIP 1283#. Frac'd perfs 1540-1949' w/15,000 gals PrePad + 2 drum Pro-Kem scale inhibitor + 52 7000# 100 mesh sand + 252,000# 16/30 brady sand and 24,000# CRC sand. ISIP 2800	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) Starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041#
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) Starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041#
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041# OCT - 9 1995 OCT - 9 1995
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) Starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041#
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041# OCT - 9 1995 OCT - 9 1995
☐ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Casing Repair ☐ Altering Casing ☐ OtherCompletion_ Perf'd w/1 SPF as foll [1572', 1579', 1596', 1696', 1703', 1710', 1718', 1726', 1748', 1772', 1800', 181 [1894', 1902', 1905', 1910', 1917', 1934', 1937', 1949' for a total of 31 holes (.4) [Action of the complete of t	Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) starting any proposed work. If well is directionally drilled, give lows 1540',1546',1562',1568',1570', 5', 1832', 1856', 1882', 1884', 1886', 0" EHD Holes). 1,000 gals 30# X-link gel water + 0#, Closed at 2041# OCT - 9 1995 OCT - 9 1995