

FORMATION RECORD—Continued

FROM—	TO—	TOTAL FEET	FORMATION
			San Andres 662'
			Olarieta 2280'
			Wolfcamp 6058'
			Mississippi an 9680'
			Dewon an 10,235'
			Permian 10,842'
			Wentzler 11,206'
			Plugs:
			7740-8020' w/38 sacks cement
			6008-6100' w/38 sacks cement
			3950-4050' w/38 sacks cement
			650-800' w/38 sacks cement
			400-450' w/20 sacks cement
			5 sacks cement surface with steel pipe marker.

It is of the greatest importance to have a complete history of the well. Please state in detail the dates of redrilling, together with the reasons for the work and its results. If there were any changes made in the casing, state fully, and if any casing was "sidetracked" or left in the well, give its size and location. If the well has been dynamited, give date, size, position, and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position, and results of pumping or bailing.

HISTORY OF OIL OR GAS WELL

16-48094-2 U. S. GOVERNMENT PRINTING OFFICE