(July 1989) (Formerly 9–331) (Formerly 9–331) UNIC J STATES DEPARTMENT OF THE INTERIOF BUREAU OF LAND MANAGEMENT	CONTACT RECEIVING OFFICE FOR NUMBI OF COPIES REDUIRI (Other Instructions on re verse side)	Modified NMD60-316	0-4 NATION AND BERIAL NO.
SUNDRY NOTICES AND REPORTS ON (Do not use this form for proposals to drill or to deepen or plug back Use "APPLICATION FOR PERMIT—" for such propos	WELLS to a different reservoir. sals.)	G. IF INDIAN, A	LLOTTEE OR TRIBE NAME
011, GAN DOTHER P&A		7. UNIT AGREEM	ENT NAME
YATES PETROLEUM CORPORATION	3n. Aren Code & Phone No 505≠748+1⊕71	8. FARM OR LEA Scheurich 9. WBLL NO.	
105 South 4th St., Artesia, NM 88210		1	
105 South 4th St., Artesia, NM 88210 LOCATION OF WELL (Report location clearly and in accordance with any State See also space 17 below.) At surface	c requirements 9 '90	10. FIELD AND P	POOL, OR WILDCAT
1980' FSL & 660' FWL, Sec. 3-T19S-R25E			raw SA Yeso
	$\zeta_{+} \subset 0.$	11. SEC., T., E., J SURVEY O	E ARDA
$\mathcal{A}$ , $\mathcal{K}_{\mathcal{U}}$	ARTESIA, OFFICE	Unit L, S	NMPM ec 3-T19S-R25E
4. FERMIT NO. 15. ELEVATIONS (Show whether DF, RT, C	GR, etc.)		PARISU  13. STATE
3524' DF		Eddy	NM
Check Appropriate Box To Indicate Natur	e of Notice Paret - (		
NOTICE OF INTENTION TO :			
	DaseCi Description	UENT REPORT OF:	
TEST WATER SHUT-OFF PULL OR ALTER CASING	WATER SHUT-OFF	REPAI	BING WELL
RACTURE TREAT MULTIPLE COMPLETE	FRACTURE TREATMENT	!	ING CABING
REPAIR WELL CHANGE FLANS	SHOOTING OR ACIDIZING	ABAND	ONMENT* XX
(Other)	(Norr: Report results Completion or Recompletion	of multiple compl	etion on Well
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent deta proposed work. If well is directionally drilled, give subsurface locations a nent to this work.) *			
5-23-90. TIH w/tubing to 1800'. Loaded hol 25 sacks plug. Waited 2 hrs. Tagged plug a	LM, Carlsbad, NM. Le with 10# brine mat 1580' Spotted	mud. Spotte	ed
5-23-90. TIH w/tubing to 1800'. Loaded hol 25 sacks plug. Waited 2 hrs. Tagged plug a 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine m at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3	35 sacks p acks plug fi	lug from rom 900-700'
25 sacks plug. Waited 2 hrs. Tagged plug a 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa	le with 10# brine m at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3	35 sacks p acks plug fi	lug from rom 900-700'
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine m at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3	35 sacks pl acks plug fr Installed dr	lug from rom 900-700'. ry hole
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine m at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3	35 sacks pl acks plug fr Installed dr	lug from rom 900-700'. ry hole
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine m at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3	35 sacks pl acks plug fr Installed dr	lug from rom 900-700'
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3 ative.	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3 ative.	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine m at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole JUN 8 RECEIVE
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine nat 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. Stative. Cative. Post ID-2 6-29-90	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. 3 ative.	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole CAR B ID 17 IN B ID 17 IN
25 sacks plug. Waited 2 hrs. Tagged plug at 92 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent	le with 10# brine nat 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. Stative. Cative. Post ID-2 6-29-90	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole CARE B RECEIVE
25 sacks plug. Waited 2 hrs. Tagged plug at 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfa marker. Plugging witnessed by BLM represent Well plugged and abandoned 5-23-90.	le with 10# brine nat 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. Stative. Cative. Post ID-2 6-29-90	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole CAR B ID 17 IN B ID 17 IN
25 sacks plug. Waited 2 hrs. Tagged plug at 350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfamarker. Plugging witnessed by BLM represent Well plugged and abandoned 5-23-90. 1 hereby certify that the foregoing is true and correct	le with 10# brine nat 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. Stative. Cative. Post ID-2 6-29-90	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole CAR B ID 17 IN B ID 17 IN
<ul> <li>25 sacks plug. Waited 2 hrs. Tagged plug at 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfamarker. Plugging witnessed by BLM represent Well plugged and abandoned 5-23-90.</li> <li><sup>1</sup> hereby certify that the foregoing is true and correct SIGNED</li></ul>	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. T tative. Post TD-2 6-29-90 PFA	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole Jun 8 RECEIVED
<ul> <li>25 sacks plug. Waited 2 hrs. Tagged plug at 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfamarker. Plugging witnessed by BLM represent Well plugged and abandoned 5-23-90.</li> <li><sup>1</sup> hereby certify that the foregoing is true and correct SIGNED manufa and and and correct TITLE Product (The space for Federal or State office use)</li> </ul>	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. T tative. Post ID-2 6-29-90 PYA	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole CAR B CEIVED B ID 17 IN 50 6-7-90
<ul> <li>25 sacks plug. Waited 2 hrs. Tagged plug at 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfamarker. Plugging witnessed by BLM represent Well plugged and abandoned 5-23-90.</li> <li>Vell plugged and abandoned 5-23-90.</li> </ul> I hereby certify that the foregoing is true and correct SIGNED muta for the foregoing is true and correct TITLE Product (This space for Federal or State office use)	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. T tative. Post TD-2 6-29-90 PFA	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole Jun 8 RECEIVED
<ul> <li>25 sacks plug. Waited 2 hrs. Tagged plug at 1350-900'. Waited 2 hrs. Tagged plug at 92 Tagged plug at 750'. Spotted 10 sacks surfamarker. Plugging witnessed by BLM represent Well plugged and abandoned 5-23-90.</li> <li>Vell plugged and abandoned 5-23-90.</li> </ul> I hereby certify that the foregoing is true and correct signed with the foregoing is true and correct signed with a state office use) TITLE Product (This space for Federal or State office use) PETROLE	le with 10# brine n at 1580'. Spotted 27'. Spotted 35 sa ace plug. RDPU. I cative. Post ID-2 6-29-90 PFA Supervisor	35 sacks pl acks plug fr Installed dr	Lug from rom 900-700'. ry hole CAR B CEIVED B ID 17 IN 50 6-7-90

•

o make to any department or agency of the