

In order to recomplete the above well, we propose the following work:

1. Set bridge plug at 9620'.
2. Perforate 9550 to 9590 with two shots per foot.
3. Run tubing with drillable retainer and set at approximately 9540.
4. Cement with 150 sacks Slo-set.
5. Perforate 9513 - 9523.
6. Run tubing, swab, and test.
7. Stimulate if necessary.