

13 hr., Flow, Rec 0 oil. Rise PKR lower & Ret. RBP @ 1885. POH left RBP in hole, RIH w/ Ret. tool & 2-3/8. latch RBP @ 1885, POH w/ RBP & 2-3/8, RIH w/ 5½ Double-set PKR & 2-3/8 set PKR @ 1604, 6 hr. Swab. Rec 0 oil.

Swab 2½ hrs. Rec. 0 BO. Lower watson 5½ PKR, thru perfs. to 2270, POH w/ PKR & 2-7/8 tbg. RIH w/ 2-3/8 tbg w/ pump/setup, TS 2279, SN 2246, RIH w/ 2x12x1½ pump & rods.

9-17 24 hrs, P, 5 bo, 28bw, 10x48x1½,