

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals, and Natural Resources Department

Form C-103 *158*
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

NOV 17 1993

WELL API NO.

30-015-02283

5. Indicate Type of Lease

STATE ☒ FEE

6. State Oil & Gas Lease No.

State 648 Milman 7 Rivers E

7. Lease Name or Unit Agreement Name

State 648 Milman 7 Rivers E

8. Well No.

176

9. Pool name or Wildcat

Milman 7 Rivers East

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

DEKALB Energy Company % Steve Smith

3. Address of Operator

P.O. Box 10513, Bakersfield, CA 93389

4. Well Location

Unit Letter N : 330 Feet From The South Line and 2310 Feet From The West

Section 21

Township 19S

Range 28E

NMPM

Eddy

Cor

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3409' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDON ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

11/9/93 Move in and rig up Baber rig. Run in hole with 2 3/8" tubing to 1118'.
Equalize 25 sacks cement. Trip out of hole and shut down for night.

11/10/93 Trip in hole with tubing, tag cement at 811'. Trip out of hole, rig up wire-
line, shoot 4 holes at 745'. Trip in hole with 4 1/2" cement retainer, set at 695
squeeze 25 sacks cement. Trip out of hole, rig up wireline, shoot 4 holes
at 500'. Trip in hole with 4 1/2" cement retainer, set at 160', squeeze
50 sacks cement. Mix 12 sacks cement and fill 4 1/2" and 7' casing.
Rig down and move off location.

11/14/93 Remove rig anchors, cleaned location, installed well marker, and
restored location.

Print ID-2
1-7-93
PYA

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Steve Smith

TITLE

Agent

DATE

11/15/93

TYPE OR PRINT NAME

Steve Smith

(805) 833-1032

TELEPHONE NO.

(This space for State Use)

APPROVED BY

Johnny Robinson

TITLE

DATE

11-15-93