

TOPS

Salade	398
B Salade	515
Gates	740
7 Powers	1130

← surface plug 0' to 60'
Perf & squeeze

7" @ 425'
CIRC.
8" hole
100%

← plug 379' to 479'
Perfisguero TAG
479' ← TOC calc. @ 50%

← plug 615' TAG

1130' - ← plus 1125' TAG
1178' ← ports

4 1/2 @ 1246
1005x
6 3/8" hole

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, **if no cement exists.**
- * Plugs to be tagged will be indicated.

MLB