

Operator SDX Resources, Inc.
 Well State 1648' # 175
 Unit B Section 22 Township 14 Range 78
 API # 30-015-02292

TOPS

Gates 752
 Drivers 1097

← CMT Plug Surface.

← Shoe Plug TAG
 (531' - 431')

← CMT Plug TAG
 @ 1000'

7" @ 481
 CIRC?
 75 SXS

Tcc
 ? 570'

Perfs. 1100' - 1215'

4 1/2" @ 1214'
 SC SXS

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

[Handwritten signature]