

Operator LDNG
 Well State 'A' #1
 Unit 1- Section 24 Township 14 Range 28
 API # 30-015-02300

TOPS

Surface	402'
B. Salt	740'
Yates	975'
W. Yates	1300'
Queen	1760'
W. Queen	2098'
San Andres	2513'

Surface plug 0' to 60'
 Perf both csg. strings &
 squeeze cement.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

8 5/8" @ 290'
 w/ 50 sacks cement
 10" hole

Shoe plug 248' to 348'
 Perf & squeeze
TAG

plug 840' - TAG

1915' ← TOC calc @ 50%
 2129' - 2192' ← plug 2120' - TAG
 ← perfor

4 1/2" @ 2720'
 @ 150 sacks cement
 8" hole

MLB