

TOPS

Salado	~375
B Salt	~440
Yates	~650
7 Rivers	1050

← Surf Ring

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, **if no cement exists.**
- * Plugs to be tagged will be indicated.

7" C 198"
SC OXS
CIRC

← short pieces 150'-250' long.

455' —→ Est TOC
← Plug 540' Tag
← Plug 1075' Tag

1126' -
1130

4 1/2" @ 1150
100 x 5