

30 015 03548 -

G-3-19-29

Webb Oil Co.

Turkey Track Sec 3 #8

Tops

T. SALT - 295'

B. SALT - 935'

* Perforate 7" casing @ 50'. Circulate cement to surface inside & outside 7" casing.

* Perforate 7" casing @ 320'. Squeeze 100' cement Plug inside & outside 7" casing. TAG

* Perforate 7" casing @ 1200'. Squeeze 100' cement Plug inside & outside 7" casing. TAG

* Circ. mud gel to surface.

* Run & set CIBP @ 2025' w 35' cement on Top.

T. Perf. - 2084' - 2106'

 CIBP w/35' cement @ 2200'.

7" casing

2439'

w/40sx