

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN THE
(Other instructions
reverse side)ICATE*
on re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 029392 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

East Shugart Unit

8. FARM OR LEASE NAME

East Shugart Unit

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Shugart - Queen

11. SEC., T., R., M., OR B.L. AND
SURVEY OR AREA

Sec. 27, T-18S, R-31E

1. OIL
WELL ☒ GAS
WELL ☐ OTHER

2. NAME OF OPERATOR

Atlantic Richfield Company ✓

3. ADDRESS OF OPERATOR

P. O. Box 1978, Roswell, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

330' FSL, 330' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3646' CTF

12. COUNTY OR PARISH

Sady

13. STATE

New Mex.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Convert to WIW

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

In accordance with NMOCC Order No. R-3769 we propose to convert this well to water injection service in the Yates & Queen formation as outlined below:

1. Drill out CIBP @ 3801'.
2. Add Queen perms from 3303-3307, 3520-33, 3635-38, 3646-55, 3797-3802 & 3806-3813 w/2 JSPF. Treat w/6000 gal 15% HCl acid.
3. Set 7" 20# CIBP @ 3850'.
4. Run 2 strings of 2" tubing w/Baker 415-D packer set @ 2770' (for Queen injection) and dual packer set @ 2560'.
5. Load 7" annulus w/treated fresh water and start water injection.

Work to start about 8/4/69

AUG 5 - 1969

O. D. B.
ARTESIA, OFFICE

RECEIVED

AUG-4 1969
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

RECEIVED

AUG 5 - 1969

O. D. B.

ARTESIA, OFFICE

18. I hereby certify that the foregoing is true and correct

Original Signed

SIGNED O. D. Bretches

TITLE

Dist. Dirg. Supervisor

DATE

8/1/69

(This space for Federal or State office use)

TITLE

DATE

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

APPROVED

AUG 4 - 1969

R. L. BECKMAI.

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-565229

937-851

RECEIVED
JUN 1 1964
U.S. DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

APPROVED
JUN 1 1964
U.S. DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT