

P & A
not in comp

Injection is to be through the five authorized water injection wells, all of which will be multiple completions except the Shugart A Well No. 8. This well will be a single completion, and injection shall be down plastic-coated tubing set in a packer near the shoe. Injection into the multiply-completed wells shall be down tubing through Baker flow valves into each of the zones being flooded. Packers shall be used to separate the zones and a packer shall be installed above the uppermost injection zone in each well. The casing-tubing annulus in all of the wells shall be filled with an inert fluid and left open or equipped with a pressure gauge to facilitate detection of tubing or packer leaks.

W111 or Ann R-3421

