

Operator SWK Operating Co. -
 Well Shugart #3
 Unit N Section 33 Township 18 Range 31
 API # 30-015-05672

TOPS

T. Salt 900
 B. Salt 2165
 Yates 2360
 Glorieta _____
 Delaware _____
 Bone Sp. _____
 Abo _____
 Wolfcamp _____
 Morrow _____
 Devonian _____
 Fusselman _____
 Other _____

← Perf 8 7/8" 5 1/2" csq. @ 60' -
 Place cmt. 0'-60' in & outside
 of Both csq. strings.

← Place 100' of cmt inside & outside csq
 805'-905' - TAG

← Perf csq @ 905'

← Place 100' of cmt 2165-2265' inside & outside csq. - TAG
 ← Perf csq. @ 2265'

3244 TOC @ 50% calc.

← 25 5x plug @ 3300' TAG

3328 3338 - Perfs Perfs sgd. Dec 82

3441 3452 - Perfs

3554' 3577 - Perfs

← Permanent Bridge Plug @ 3500' Feb. 1971

5 1/2 3625'
 100 5x
 7 7/8" hole

- Contact OCD 24 hrs. prior to any work done
- Salt gel mud consisting of 10# brine with 2 of gel per barrel must be placed between ea plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sack of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.