

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1-
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
State OG-16	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry Hole</b>		7. Unit Agreement Name
2. Name of Operator <b>Western Oil Fields, Inc. ✓</b>		8. Farm or Lease Name <b>State OG-16</b>
3. Address of Operator <b>P.O. Box 1137, Hobbs, New Mexico</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>1650</b> FEET FROM THE <b>South</b> LINE AND <b>1650</b> FEET FROM THE <b>West</b> LINE, SECTION <b>10</b> TOWNSHIP <b>19S</b> RANGE <b>29E</b> NMPM.		10. Field and Pool, or Wildcat <b>Turkey Track</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3380.8 GR</b>		12. County <b>Eddy</b>

### 16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

R.U. Well Service unit, pulled 2½" tubing, ran 2½" tubing to 2000 feet, loaded hole with 9.8# mud. Spotted 25 sack plug (cement) from 2000 feet back to 1800 feet. (Perfs 2195-2223) Pulled 2½" tubing. Ran Free Point - cut off casing at 1550. Pulled 48 jts 5½" casing. Ran 2½" tubing to 1140' and spotted 25 sack plug from 1140' back 1042'. (Base of salt 1030) Spotted 15 sack plug in and out of 8-5/8" casing at 368'. Installed 4" X 10' marker and cemented with 10 sacks. Marker is 4' above G.L. Cleaned location, took out deadmen. Location ready for inspection. Official P & A time 6:00 P.M. (4-7-67) Marker identifies well location.

RECEIVED

APR 11 1967

APR 11 1967

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Paul Swiate TITLE Division Engineer DATE 4-12-67

APPROVED BY P. F. Starnes TITLE Division Engineer DATE 4-12-67

CONDITIONS OF APPROVAL, IF ANY: