

Operator Webb Oil Company
 Well Saverton Union #217
 Unit H Section 30 Township 19 Range 31
 API # 30-015-20248

TOPS

Rustler	303'
Salada	553'
Base Salt	1878'
Gates	2052'

← Plug 60-0' surf.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

8 5/8" @ 580'
CIRC

← Plug 630'-430'
Per 5' Spuz. TAG

T.O.C
1564
C.A.I. @ 5670

Per 5s. 1717'-2085'

← Plug 1867' TAG

5 1/2" @ 2282'
200 SXS

← Plug 2282' TAG

T.O.
2250'

[Handwritten signature]