

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL CONS COMMISSION
Drawer DD
Artesia, NM 88210

BLM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FSL & 660' FEL of Section 23-T19S-R24E (Unit 1, NESE)

5. Lease Designation and Serial No.

NM-26864

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Roden GD Federal #1

9. API Well No.

30-015-70122

10. Field and Pool, or Exploratory Area

North Dagger Draw Upper Penn

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon well as follows:

1. Nipple down tree and nipple up BOP. POOH with tubing and packer and guns at 8300'.
2. Set CIBP at 8800' and cap with 35' of cement to abandon Morrow perms. 8883-8887".
3. Set CIBP at 8300' and cap with 35' of cement to abandon Strawn perms. 8357-8397".
4. Set CIBP at 7500' and cap with 35' of cement to abandon Canyon perms. 7540-7767".
5. Fill hole with 10 ppg salt gel containing 25# per barrel water.
6. Determine free point of 4-1/2" production casing. Cut and pull as much casing as possible. CBL indicates top of cement at 6830'.
7. Spot a 50 sack cement plug (150' plug in open hole) across 4-1/2" casing stub. Tag plug.
8. Spot a 50 sack Class C cement plug from 2190-2020' to cover intermediate casing shoe at 2100'. Tag plug.
9. Spot a 40 sack Class C cement plug from 520-370' across surface casing shoe at 442'. TAG PLUG.
10. Spot a 25 sack Class C cement plug from 92' to surface.
11. Install regulation abandonment marker.

NOTIFY BLM (887-6544) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title Production Clerk

Date Oct. 11, 1994

(This space for Federal or State office use)

Approved by Orig. Signed by Adam Salameh

Title Petroleum Engineer

Date 11/7/94

Conditions of approval, if any:

- SEE ATTACHED -

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side