orm 3160-5 June 1990)		N.M. Oil Cons_Divis STATES 811 S. 1st Stre F THE INTERIOR D MANAGEMENTARtesia, NM 88210-28	FORM APPROVED
Do not use this	SUNDRY NOTICES AND	D REPORTS ON WELLS to deepen or reentry to a different reservo	NMNM 15291 6 If Indian Allottee or Tribe Name
	SUBMIT IN 1	<i><b>TRIPLICATE</b></i>	7. If Unit or CA, Agreement Designation
<ol> <li>Type of Well Oil Gas Well Well Other</li> <li>Name of Operator Nearburg Producing Company</li> <li>Address and Telephone No.</li> <li>3300 N A St., Bldg 2, Suite 120, Midland, TX 79705</li> <li>Location of Well (Footage, Sec., T., R., M., or Survey Description) 660' FSL and 1980' FWL, Section 34, T19S, R25E</li> </ol>			8. Well Name and No. Irami Federal #1
			9. API Well No. 30-015-21115 10. Field and Pool, or Exploratory Area
			Seven Rivers Yeso 11. County or Parish, State
			Eddy County, NM
2. CHE	CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA		
	E OF SUBMISSION	TYPE OF ACTION Abandonment Recompletion	N Change of Plans New Construction
	ubsequent Report nal Abandonment Notice	Plugging Back Casing Repair Altering Casing Other Other	Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water
directionally drine		and true vertical depths for all markders and zones pertinent to the	
<ol> <li>2.) Spot 15 sxs</li> <li>3.) Spot 25 sxs</li> <li>4.) Spot 45 sxs</li> <li>5.) Spot 45 sxs</li> <li>6.) Spot 45 sxs</li> <li>7.) Set cement</li> <li>8.) Install dry h</li> </ol>	s @ 2270'.	)P - 2318'.	11-1-2027
<ol> <li>2.) Spot 15 sxs</li> <li>3.) Spot 25 sxs</li> <li>4.) Spot 45 sxs</li> <li>5.) Spot 45 sxs</li> <li>6.) Spot 45 sxs</li> <li>7.) Set cement</li> <li>8.) Install dry h</li> </ol>	s @ 2318'. s @ 2270'. s @ 1657'. s @ 1350' - 1212' s @ 540' - 405'. t plug 50' to surface. tole marker.	אָרָרָיָרָיָרָיָרָיָרָיָרָאָרָיָרָאָרָאָ	ALCENCE AND
<ul> <li>2.) Spot 15 sxs</li> <li>3.) Spot 25 sxs</li> <li>4.) Spot 45 sxs</li> <li>5.) Spot 45 sxs</li> <li>6.) Spot 45 sxs</li> <li>7.) Set cement</li> <li>8.) Install dry h</li> <li>9.) RDMO unit</li> </ul>	s @ 2318'. s @ 2270'. s @ 1657'. s @ 1350' - 1212' s @ 540' - 405'. t plug 50' to surface. tole marker.	DP - 2318'.	Date 05/08/00
<ul> <li>2.) Spot 15 sxs</li> <li>3.) Spot 25 sxs</li> <li>4.) Spot 45 sxs</li> <li>5.) Spot 45 sxs</li> <li>6.) Spot 45 sxs</li> <li>7.) Set cement</li> <li>8.) Install dry h</li> <li>9.) RDMO unit</li> </ul>	s @ 2318'. s @ 2270'. s @ 1657'. s @ 1350' - 1212' s @ 540' - 405'. t plug 50' to surface. hole marker. FINAL REPORT. hat the foregoing is true and correct aral of State office used SGD.) GARY GOURLEY		Date 05/08/00

-----

