

Recommended Work Procedure

A.F.E. No. 441

David Fasken - Seven Rivers Federal No. 1
Cemetery, North (Wolfcamp) Field
Eddy County, New Mexico

15. Set 5 sacks cement plug in 8-5/8" casing.
16. Weld steel plate on top of well with marker.
17. Disconnect all surface equipment.
18. Clean-up well and battery site.
19. Rip pad and road.

RECEIVED

OCT 17 1979

U.S. DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
ALBUQUERQUE, NEW MEXICO