

30-015-638

F-23-195-8e

I.T. Properties

D.R.V. STATE #1

Tops

T. SALT - 950'

B. SALT - 1380'

T. S.A. - 2690'

T. Gloria - 4255'

T. Wolfcamp - 8815'

T. Morrow - 10,810'

* Set 10 sx surface Plug.

* Perforate 5 1/2" casing @ 467'

Squeeze 100' cement Plug
inside + outside 5 1/2" casing. TAG

* Perforate 5 1/2" casing at 2850'. Squeeze 100' cement Plug
inside + outside 5 1/2" casing. TAG

* Perforate 5 1/2" casing at 5766'. Squeeze 100' cement Plug
inside + outside 5 1/2" casing. TAG

* Run + set CIBP w/35' cement at 8766'.

* Run + set CIBP w/35' cement at 10,925'.

12 3/4" casing
417' circ.

8 5/8" casing
2800'

Toc - 541'

emp. survey

5 1/2" casing
11,553'

Toc

6880' Temp. Survey

Perfs 8866' - 8902'

* Brine gel between all Plugs

Perfs 11,025' - 47'

* Erect dry hole marker

cut + level all pits

cut + remove all Deadmen.

Remove junk from location