

Operator SW Royalties, Inc.
Well Julie Com. #1
Unit H Section 17 Township 19 Range 25
API # 30-015-21863

TOPS

San Andes	~ 900'
Glenide	2150'
Abc	4750'
Wolfcamp	6460'
Upper Penn	7663'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated **up**.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if **no cement exists**.
- * Plugs to be tagged will be indicated.