

FILE: GREENA BRIEF A VM/XA SP 2.1 CMS 5.6

GREENWOOD PRE-GRAYBURG UNIT FEDERAL "A" COM NO. 1  
PLUG AND ABANDON  
SHUGART MORROW FIELD  
EDDY COUNTY, NEW MEXICO

1. RUSU X POH W/ PROD EQUIP.
2. SET CIBP AT 11,450' X CAP W/ 35' CMT.
3. LOAD HOLE W/ MUD.
4. SET CIBP AT 11,000' X CAP W/ 35' CMT.
5. LOAD HOLE W/ MUD.
6. SPOT 100' CMT PLUG FROM 4650' TO 4550'.
7. LOAD HOLE W/ MUD.
8. SPOT 100' CMT PLUG FROM 815' TO 715'.
9. LOAD HOLE W/ MUD.
10. CAP W/ 15 SX CMT PLUG AT SURFACE.

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT:

	WORK	USERID	HOME
BRIAN TAYLOR	8-321-7301	ZBWT03	713-578-7501
TERRY CALDWELL	8-321-7286	ZTAC17	713-975-9863