

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Oil Cons.
N.M. Div-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210

BUDGET BUREAU NO. 1504-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 30062

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Long Box # 1

9. API Well No.

30-015-22624

10. Field and Pool, or Exploratory Area

Tres Hombres Atoka

11. County or Parish, State

Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Pronghorn Management Corporation

3. Address and Telephone No.

P. O. Box 1772 Hobbs, NM 88241 505-393-9176

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FNL & 660' FEL
S30-T20S-R24E

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☒ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Move in & Rig up. Install B.O.P. Tag CIBP @ 8385' W/35' Cement
 2. POOH with tubing & packer.
 3. Set C.I.B.P. @ $\pm 8000'$. Cap with 35' cement. - Tag
 4. Perforate Cisco Canyon.
 5. Swab test well. Treat as necessary.
 6. If not productive, set C.I.B.P. @ $\pm 7000'$. - Tag
Cap w/35' cement
 7. Perforate AB@. *Perforate @ 6000' & Squeeze W/500SX.*
 8. Swab test well. Treat as necessary.
 9. If not productive, prepare to P&A well. Circulate hole w/mud laden fluid.
 10. Nipple up to 4 1/2" casing. Stretch, cut & pull casing.
 11. Spot 100' cement plug. 50' in and 50' out of 4 1/2" stub $\pm 5000'$. - Tag
 12. Set 100' cement plug 2763' - 2863'.
 13. Set 100' plug @ 8 5/8" shoe. 50' in and 50' out 1875' - 1975'. Tag.
 14. Set 100' plug @ 13 3/8" shoe. 50' in and 50' out. 345' - 445'. - Tag
 15. Set 50' surface plug. Erect dry hole marker.
 16. Clean location. Move out equipment.
- *Mud laden fluid to be circulated with all plugs.

Accepted for record - NMOCD

14. I hereby certify that the foregoing is true and correct

Signed [Signature] Title Partner Date 2-12-02

(This space for Federal or State Use)

Approved by (ORIG SGD) DAVID R. GLASS

FEB 13 2002

Title _____ Date _____

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

PETROLEUM ENGINEER

*See Instruction on Reverse Side

BUREAU OF LAND MANAGEMENT
HORNELL OFFICE

2002 FEB 13 AM 8:56

RECEIVED

FEB 13 2005