

- Set CIBP w/ 35' cmt above Strawn perts
9400' - 9500'.
- 100' cmt plug @ 8500 - 8600'
(Set above Wolfcamp).
- 100' cmt plug across zone at DV Tool.
7070 - 7170'.
- Perf & sqz 100' cmt inside & outside of casing
@ 5200' where calc too
- 100' cmt plug at 8 5/8 casing shoe
2558 - 2658 Tag.

91 685 0533