

Operator SIRO Corp
Well FOFO#
Unit E Section 32 Township 19 Range 27
API # 30-015-22868

TOPS

T. Salt _____
B. Salt _____
Yates _____
Glorieta _____
Delaware _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

7 R. Jans 156

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up.
- Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

60' Surface Plug

7" ← 190' — TA1

197' OH
650'

30-015-22868

6.6520

Oxford[®]

⊗ ESSELTE

MADE IN U.S.A.

NO. R753 1/3

• • • •

7-29-80
sidewall flint. Pw.

23-693