

30-015-23312

C-3-195-29c

Webb Oil Co.

Turkey Tract #23.

Tops
T. Salt - 390'
B. Salt - 950'

* Perforate $4\frac{1}{2}$ " csg $\rightarrow$ 30'. circulate cement to surface.

* Perforate $4\frac{1}{2}$ " csg $\rightarrow$ 390'. Squeeze cement 100' cement Plug.
Inside & Out side $4\frac{1}{2}$ " csg. TAG

* Spot 2558 cement Plug 1000'-900'. TAG

* Circulate brine gel.

* Spot 2558 cement Plug 2000'. TAG

= Perfs - '.

$4\frac{1}{2}$ " csg

$\rightarrow$ 2950'

ROC - 500'

by Temp. survey.